

Please read this manual carefully
before use!

User Manual



Gasoline log splitter

KS 15TKG 52/35

KS 27THG 65/55






Fig. 1




Fig. 2



Fig. 3




Fig. 4

For horizontal use






Fig. 5
For vertical use




Fig. 6
For vehicle towing




Fig. 7






Fig. 8






Fig. 9

Step 1







Step 2



Step 3



Step 4



Step 5






Fig. 10






Fig. 11

Step 1







Step 2




Step 3




Step 4




Step 5



Step 6




Step 7






Step 8



Step 9



Step 10





Fig. 12





Gasoline log splitter

- KS 15TKG 52/35
- KS 27THG 65/55



INTRODUCTION

Thank you for choosing **Könnér & Söhnen®** products. This manual provides a brief description of safety requirements, setup procedures, and operating instructions. More information is available in the support section at:

konner-sohnen.com/pages/instructions

You can also download the manual by scanning the QR code or by visiting the official importer's website at **www.konner-sohnen.com**



| Please, read this manual before use!

The manufacturer reserves the right to make changes that may not be reflected in this manual, including:

- The manufacturer reserves the right to make changes in the product design, configuration and construction.
- The images and drawings in this manual are for reference only and may differ from the actual components and inscriptions on the products.

Contact information for technical support is provided on the official website. All information in this manual is correct to the best of our knowledge at the time of publication. The current list of service centers can be found on the official importer's website at **www.konner-sohnen.com**

⚠ ATTENTION – DANGER! Failure to follow the recommendations marked with this sign may lead to serious injury or death of the operator or third parties.

⚠ IMPORTANT! Useful information while operating the machine.



SAFETY INFORMATION

⚠ WARNING! Please, read this manual carefully before use!

Protecting yourself and those around you

⚠ WARNING! This is a high-powered machine, with moving parts operating with high energy. You must operate the machine safely. Unsafe operation can create a number of hazards for you, as well as anyone else in the nearby area.

Always take the following precautions when using this machine:

- Always wear protective goggles or safety glasses with side shields while using the log splitter to protect your eyes from possible thrown debris.
- Avoid wearing loose clothing or jewelry, which can catch on moving parts.
- We recommend wearing gloves while using the log splitter.
- Wear shoes with non-slip treads when using your log splitter. Do not use the machine while barefoot or wearing open toed sandals.
- Wear long pants while operating the log splitter.
- Keep bystanders at least 50 feet away from your work area at all times. Stop the motor when another person or pet approaches.
- Never allow children to operate the log splitter.
- Keep in mind that the operator or user is responsible for accidents or hazards occurring to other people, their property, and themselves.



SAFETY WITH GASOLINE - POWERED MACHINES

⚠ WARNING! Gasoline is a highly flammable liquid. Gasoline gives off flammable vapor that can be easily ignited and cause a fire or explosion.

Always follow these precautions:

- Never run the engine in an enclosed area or without proper ventilation as engine exhaust contains carbon monoxide, which is an odorless, tasteless, and a deadly poisonous gas.
- Replace rubber fuel lines and grommets when worn or damaged and after 5 years of use.
- Fill the fuel tank outdoors with the engine off and allow the engine to cool completely.
- Allow the engine to cool completely before storing. Never store a machine with gasoline in the tank or a fuel container.
- Never make adjustments or repairs with the engine running. Shut down the engine, disconnect the spark plug wire while keeping it away from the spark plug to prevent accidental starting, and then wait 5 minutes before making adjustments or repairs.
- Never tamper with the engine governor setting.
- Never cover the machine while the muffler is still hot.
- Do not operate the engine with the air filter or the carburetor air intake cover removed. Removal of such parts could create a fire hazard. Do not use flammable solutions to clean the air filter.
- The muffler and engine become very hot and can cause severe burns; do not touch them.



SPECIFICATIONS

Model	KS 15TKG 52/35	KS 27THG 65/55
Log splitter type	kinetic	hydraulic
Engine power	6.5 hp	6.5 hp
Splitting force	15 ton	27 ton
Engine type	gasoline	gasoline
Engine model	KS 230	KS 230
Max. splitting length	520 mm	650 mm
Max. splitting diameter	350 mm	550 mm
Cycle time	~ 2 sec.	~ 15 sec.
Operating position	horizontal	vertical/horizontal
Flywheel speed	450 rpm	–
Fuel tank volume	3.6 l	3.6 l
Hydraulic oil volume	–	20 l
Crank case volume	0.6 l	0.6 l
Wheels	12"	16"×4.8-8 4, support wheel with brake
Gross dimensions (L×W×H)	1450×390×710 mm	2250×505×570 mm
Net weight	120 kg	260 kg
Protection class	IP54M	IP54M

⚠ IMPORTANT! The diameter listed is indicative of the maximum suggested size. A small log can be difficult to split when it contains knots or a particularly tough fiber.



EC Declaration of Conformity

Gasoline log splitter "Könner & Söhnen"

Könner & Söhnen® declares that these products described below

KS 15TKG 52/35, KS 27THG 65/55

Technical data are in compliance with 2006/42/EC, 2014/30/EU, 2000/14/EC.

EN ISO 12100:2010

EN 609-1:2017

EN 55014-1:2017

EN 55014-2:1997/A2:2008

EN 61000-3-2:2014

EN 61000-3-3:2013

These products also comply with 2006/42/EC Machinery Directive, 2000/14/EC Noise Directive (amended by 2005/88/EC), 2014/30/EC Electromagnetic compatibility Directive, (EU) 2016/1628 Non-Road mobile machinery emissions.

For more information, please contact Könner & Söhnen® at the following address or refer to the back of the manual.

The undersigned is responsible for compilation of the technical file and makes this declaration on behalf of Könner & Söhnen®.

P. Fomin

Director, 8 Flinger Broich 203, 40235 Duesseldorf, Germany:

11.05.2026

DIMAX

International GmbH

Flinger Broich 203 40235 Düsseldorf

US-ID DE296177274

koenner-soehnen.com

P. Fomin

REACH Regulation (EC) No. 1907/2006

The manufacturer confirms that this product complies with the requirements of the REACH Regulation concerning the restriction of substances of very high concern (SVHC). We confirm that supplied parts comply with REACH Regulation (EC) 1907/2006 and contain no SVHC above 0.1%

Based on information received from component suppliers, no SVHC are present in concentrations exceeding the limits defined by the regulation.

This declaration is made on the basis of self-assessment and supplier statements.

RoHS Directive 2011/65/EU

This product contains electrical and electronic components that are subject to the RoHS Directive 2011/65/EU.

Based on information and test reports provided by component suppliers, the manufacturer confirms that these components comply with RoHS Directive 2011/65/EU.



GETTING STARTED

Checking the fuel level

1. Unscrew the fuel cap and check the fuel level in the tank.
2. Fill the fuel tank to the fuel filter level.
3. Tighten the fuel cap securely.

Recommended fuel: use only unleaded gasoline with an octane rating of 90–95 containing no more than 10% ethanol.

Fuel tank volume: see specifications table.


⚠ IMPORTANT! Wipe up spilled fuel immediately with a clean, dry, soft cloth, as the fuel may harm painted surfaces or plastic parts.

⚠ IMPORTANT! Use only unleaded gasoline. Using leaded gasoline can cause serious damage to the inside of the engine.

Checking the oil level

The log splitter is transported free of motor oil. Do not start the engine until it is filled with sufficient amount of motor oil.

1. Unscrew the oil dipstick and wipe it out with a clean cloth.
2. Insert the dipstick without screwing it in.
3. Check the oil level by a mark on the oil dipstick.
4. Add oil if its level is below the mark on the oil dipstick.
5. Screw on the dipstick.



Recommended motor oil: SAE 10W30, SAE 10W40.

Recommended motor oil grade: API Service SG type or higher.

Motor oil quantity: 0.6 l.

Commissioning

1. Fill the crankcase with engine oil. The recommended amount of oil for each model is indicated in the specification chart.
2. Check oil level with an oil dipstick. It should be between the MIN and MAX marks on the oil dipstick.
3. Check fuel level.
4. Check the air filter for correct installation.

In the first 20 operating hours, the following requirements should be met:

1. After the first 20 operating hours, be sure to change the oil. It is better to drain motor oil while the engine is still hot after operation to ensure quick and complete oil draining.
2. Check and clean the air filter and spark plug.

Starting the engine

Before starting the engine, make sure the switch is in the "I" (ON) position (fig. 1). Turn the rotary engine speed dial to MAX. Set the engine switch to the "CHOKE" position. Grasp the starter handle and slowly pull it until resistance is felt, then pull it with a rapid movement all the way. Repeat the operation until the engine starts. After starting the engine, allow the rope to retract without throwing the starter handle. Put the flaps in the "RUN" position.

⚠ WARNING! Do not reach or step across the beam while the log splitter is running. This is a very UNSAFE method which could cause personal injury or even death.

⚠ CAUTION!

- Never attempt to split wood across the grain. The log splitter was not designed for cross-grain splitting. Doing so could damage the log splitter and may cause personal injury.
- Make sure both ends of the log you are splitting are cut as square as possible. This will prevent the log from sliding out of position while under pressure.

Stopping the engine

To stop the engine, turn the switch to the "OFF" position. Turn the fuel valve to the "CLOSED" position.



KINETIC LOG SPLITTER KS 15TKG 52/35 OPERATION INSTRUCTIONS

⚠ WARNING! The kinetic log splitter operates differently than a hydraulic splitter. Not operating the machine properly will result in damage to the machine.

Always follow these notices:

- A rapid movement of the engagement handle is necessary for the rack and pinion to engage and disengage fully without damage.
 - The engagement handle should never be stopped in any location between the fully forward or fully backward positions.
 - Do not hold the handle in the forward position when the ram stops moving forward. Always pull the engagement handle RAPIDLY to the back (auto-retract) position as soon as the log is split or when the ram is at the end of the stroke or when the ram stops moving forward due to a tough log.
1. Place the log on the Log Splitter. Grasp the log on the sides near the middle of the block. Center the log, side-to-side, on the rail of the Log Splitter. Do not place the log tightly to the cutting knife. The recommended distance from the cutting knife is 4-5 cm (fig. 2).

⚠ CAUTION! The engagement handle must be held fully in the split position against the hard stop when splitting. Failure to do so may result in kickback of the handle.

2. With one hand, actuate and hold the safety lever towards you, then RAPIDLY actuate the engagement handle fully towards the engine until it contacts the hard stop and hold firmly until the log is split.
3. IMMEDIATELY AFTER the log is split, actuate and hold the engagement handle in the auto-retract position to allow the ram to return. If the ram stops before the end of the stroke while splitting a tough log, quickly actuate the engagement handle back to the auto-retract position. Let the ram return and allow the flywheels to gain momentum for another full power split.



HYDRAULIC LOG SPLITTER KS 27THG 65/55 OPERATION INSTRUCTIONS (fig. 3, fig. 4)

1. Load a log onto the beam and against the endplate.
2. Serious accidents can happen when other people are allowed inside the work zone. Keep everyone else out of the work zone while operating the control valve.
3. Make sure hands are clear of crush hazard zones.

- 4. Push the control valve handle FORWARD with two hands to split the log.
- 5. Push the control valve handle BACKWARD with two hands to return wedge to its original position.
- 6. Remove the split wood from the work zone.

For horizontal use (fig. 4)

Rotate rear leg down and slide the lock pin.

For vertical use (fig. 5)

- 1. Pull out the beam lock pin.
- 2. Lift the beam at the end side and rotate it down slowly.

For vehicle towing (fig. 6)

Hook safety chain to tow vehicle. Rotate the rear leg and slide the lock pin.

How to split the log with slanted surface (fig. 7)



KS 15TKG 52/35 COMPONENTS IN THE PACKAGE (fig. 8)

- | | |
|--|--------------------|
| 1. Body | 7. Wheel bracket |
| 2. Operate handle | 8. Vee belt |
| 3. Safe handle | 9. Pully guard |
| 4. Engine | 10. Outtrigger leg |
| 5. Plate | |
| 6. Protective metal grill. The Könnér & Söhnen® protective metal grill protects the user from debris such as flying chips and small pieces of wood generated during splitting. | |



KINETIC LOG SPLITTER KS 15TKG 52/35 ASSEMBLY (fig. 9)



KS 27THG 65/55 COMPONENTS IN THE PACKAGE (fig. 10)

- 1. **Coupler.** Attaches the log splitter to your vehicle. Couplers vary with the market.
- 2. **Hydraulic Cylinder.** It is rated to 3500 psi.
- 3. **Control valve handle.** Use the control valve handle to move the wedge slide forward and backward. A two-handle option is only available for European market.
- 4. **Wedge.** The wedge features a taper that makes splitting easier; welded cross can be put on.
- 5. **Log cradle.** Keeps the log on the beam without operator assistance. Can be upgraded to a bigger table.
- 6. **Engine.** The air cooled engine powers the hydraulic pump.
- 7. **Tires.** Maximum rated speed is 30 mile per hour.
- 8. **Gear pump.** The gear pump makes the hydraulic oil flow through the system.
- 9. **Leg.** The leg supports the log splitter while operating. The leg should be raised while towing (see “Operation Instructions”).
- 10. **Safety chains.** A safety feature to prevent detachment of log splitter while towing.
- 11. **Protective metal grill.** Protects the user from debris such as flying chips and small pieces of wood generated during splitting.



HYDRAULIC LOG SPLITTER KS 27THG 65/55 ASSEMBLY (fig. 11)

- STEP 1: Assemble the wheel.** Fix the wheel to the oil tank by the slotted nut , cotter pin and attach the dust cap.
- STEP 2: Attach the tow bar and support leg (for model with jockey wheel).** Fix the support outrigger leg to the tow bar using the catch pin, bolt M10×75,lock nut M10 and R pin.
- STEP 3: Attach the tow bar to the oil tank.** Fix the tow bar to the oil tank using hex bolts M12 and lock nuts M12.

STEP 4: Assemble the rear support leg. Fix the rear outrigger leg to the tow bar using the catch pin, bolt M10, lock nut M10 and R pin.

STEP 5: Attach the hydraulic cylinder. Attach the hydraulic cylinder and the H-beam comb to the tow bar using beam pin #47, and lock it with R pin #16.

STEP 6: Attach the control valve. Attach the control valve assembly to the oil cylinder as shown below.

STEP 7: Attach the engine. Attach the engine to the engine setting board using hex bolt M8, the flat washer, lock washer, and lock nut.

STEP 8: Attach the hydraulic hoses. Attach all the hoses to the machine as shown below, including hydraulic oil hose A, oil hose B, oil hose C and oil suction pipe.

STEP 9: Attach the wheel fender and log cradle. 1. Attach the left fender and the right fender to the oil tank using hex bolt M8, flat washer Ø8, and lock nut M10. 2. Attached the left and right log cradles using bolt M10 and lock nut M10.

STEP 10: Attach big table.



REGULAR MAINTENANCE CHECKLIST

Comply with the instructions in this manual! You can find an updated list of service centers on the website of exclusive importer: www.konner-sohnen.com

Maintenance of air filter (fig. 12)

A dirty air filter restricts air flow into the carburetor, decreases engine performance and reduces log splitter performance. Check the air filter and clean it before every start. If the air filter is damaged, replace it. When working in extremely dirty conditions, clean the filter every 10 hours, otherwise replace it every 25 hours if needed.

⚠ IMPORTANT! Never operate the engine without air filter. The air filter prevents high-speed wear of the engine.

Spark plug maintenance

Spark plug must be intact, free of soot deposits and must have a correct gap.

SPARK PLUG CHECK:

1. Remove the cap from the spark plug.
2. Remove the spark plug by means of a corresponding spanner.
3. Examine the spark plug. If it is shattered, it is necessary to replace it. Recommended replacement spark plugs – F7RTC.
4. Measure the gap. It must be within a range of 0.7 – 0.8 mm.
5. In case of repeated use, the spark plug must be cleaned with a metal brush. After that set the correct gap.
6. Put the spark plug back in its place by means of a spark plug spanner.
7. Replace the spark plug cap.

⚠ WARNING! The equipment is sold without adaptation to the rules of operation and transportation on public roads. In each country, the responsibility for the adaptation rests solely with the buyer.

⚠ WARNING! Before long-term storage of the log splitter during the engine work close the fuel valve and let the engine to elaborate gasoline from carburetor. Wait until engine stops itself.

PROCEDURE		Every start or 20 hours	Before each use	Every 5 hours	Each 3 months or after 50 working hrs	Each 6 months or after 100 working hrs	Every year or after 150 working hrs
Motor oil	Check		✓				
	Replace	✓			✓		
Hydraulic oil for model KS 27THG 65/55	Check		✓				
	Replace						✓
Air filter	Check		✓				
	Clean out	✓					
	Replace				✓		
Check general equipment	Check		✓				
Grease surface of slide rail	Lubricate		✓	✓			
Check belts	Check	✓		✓			
Grease rack and pinion	Lubricate		✓	✓			
Clean engine exterior and cooling	Clean out			✓			
Spark plug	Gap check and control				✓		
	Replace					✓	

Lubrication

⚠ WARNING! All bearings of your splitter are sealed units and should be sufficiently lubricated to last the life of your machine with normal use.

The rack and pinion should be completely greased before every use. Before performing any maintenance procedure or inspection, stop the engine, wait five minutes to allow all parts to cool. Disconnect the spark plug wire, keeping it away from the spark plug.

Before performing maintenance, the hydraulic log splitter must be placed in maintenance mode.

1. Turn off the engine.
2. Move the control valve handle forward and backward to relieve hydraulic pressure.

After performing maintenance, make sure all guards, shields, and safety features are put back in place. Failure to follow this warning can result in serious injury.

What	When	How
Hoses	Every use	Inspect for exposed wire mesh and leaks. Replace all worn or damaged hoses before starting the engine.
Hydraulic fittings	Every use	Inspect for cracks and leaks. Replace all damaged fittings before starting the engine.
Nuts and bolts	Every use	Check for loose bolts.
Beam	Every use	Apply grease to beam surface.
Moving parts	Every use	Clear debris.

Replacing hydraulic oil for model KS 27THG 65/55

Replace the hydraulic oil in the log splitter after every 150 hours of use. Take the following steps to replace the oil:

1. Make sure all moving parts are stopped and the log splitter is unplugged.
2. Unscrew the oil drain bolt.
3. Place a drip tray under it to drain spent oil.
4. Fill with fresh hydraulic oil. As stated in the Specifications Table on page 2 the correct oil capacity is 20 L.

5. Clean the surface of the dipstick, which is attached to the oil drain bolt, with a clean lint free cloth and put back into the tank to check the new level. Make sure the level of the refilled oil is just between the two grooves around the dipstick.

6. Clean the oil drain bolt before screwing it back. Make sure it is tightened to avoid leakage before placing the log splitter horizontally.

! NOTICE! Periodically check the oil level to ensure it is between the two grooves on the dipstick. Refill when the oil reaches the lower level.

Use hydraulic oil SO VG 22.

The following hydraulic oils or equivalent are recommended for the log splitter's hydraulic transmission system:

• SHELL Tellus 22

• ARAL Vitam GF22

• MOBIL DTE 11

• BP Energol HLP-HM22



POSSIBLE FAILURES AND SOLUTIONS

Malfunktion	Possible trouble	Troubleshooting
The engine does not start	Insufficient oil in pump.	Check oil level in reservoir.
	Air in oil.	Check oil level in reservoir.
	Engine circuit breaker is in the "OFF" position.	Bring the engine circuit breaker to "ON" position.
	There is no fuel in the tank.	Add fuel, clean the fuel line.
	Clogged fuel line.	Always use fresh fuel of branded varieties, good unleaded gasoline.
	Pool, old or contaminated fuel in the tank.	Clean fuel tank, fuel line to the carburetor.
	The air filter is dirty.	Clean the air filter.
	Spark plug wire disconnected from spark plug; high voltage wires badly loosen in plug.	Insert the plug wire to the spark plug; check the connection between the high voltage wire and plug.
	Spark plug is blacken with smoke or damaged; wrong distance between the electrodes.	Clean or replace the spark plug; set the distance between electrodes.
	Engine "drowned" after several attempts to launch.	Unscrew and dry the spark plug, pull the rope several times when spark plug is off; fuel supply controller is in STOP position.
Hard start or decreased engine power	Low crankcase oil.	Add oil to the crankcase.
	The fuel tank is dirty.	Clean fuel tank.
	The air filter is dirty.	Clean the air filter.
	Spark plug is sooted.	Clean the spark plug.
Engine overheating	Water in the fuel tank and carburetor; carburetor is occluded.	Empty the fuel tank; clean the fuel line and carburetor.
	Wrong distance between spark plug electrodes.	Set the right distance between spark plug electrodes.
	The air filter is dirty.	Clean the air filter.
	Cooling ribs are dirty.	Clean the cooling ribs.
Increased vibration when working	Too low level of engine oil.	Add engine oil.
	Weakened engine mounts.	Tighten the engine screws.



WARRANTY SERVICE TERMS

The international manufacturer warranty is 2 year. The warranty period starts from the date of purchase. Within the warranty period, if the product fails because of defects in the production process, it will be exchanged on the same product or repaired.

The warranty card should be kept throughout the warranty period. In case of warranty card loss, a second one will not be provided. The customer must provide the warranty card and buyer's check during request for repair or exchange. Otherwise, the warranty service will not be provided.

Provide clean product to the service center. Parts, that must be replaced, are the property of the service center.

■ Warranty exclusion:

- The user has failed to comply with the instructions in this manual.
 - The product features damaged or missing identification stickers or labels, serial numbers, etc.
 - Product malfunction was due to improper transportation, storage and maintenance.
 - In case of mechanical damages (cracks, chips, impact and fall marks, deformation of housing, power cord, plug or any other components), provided there are foreign objects inside the unit.
 - Proper operation of the product can be restored following cleaning from dust and dirt, appropriate adjustment, maintenance, etc.
 - Faults have been caused by product overload.
 - If electrical cables or plugs show signs of mechanical or thermal damage.
 - In the event of foreign liquids and objects, metal chips, etc. inside the product are found.
 - The damage caused by natural factors such as dirt, dust, humidity, high or low temperature, failures due to acts of God or natural disasters, which are beyond manufacturer's control (such as earthquake, tornado, fire, war, earthquake, etc.)
 - Normal wear parts and accessories (fuses, bulbs, keys, buttons, plastic and rubber parts, chargers for Lithium batteries, filters and consumables, etc., as well as normal wear)
 - Preventive maintenance (cleaning, washing), installation and adjustment.
 - The product was modified or altered.
 - In case of malfunctions resulting from normal wear and tear as a result of long-term use (end of life), cosmetic defects.
 - Product operation was not stopped and continued after detecting a malfunction.
-

CONTACTS

Deutschland:

Hergestellt unter Lizenz und Kontrolle der DIMAX International GmbH.

Importeur und Vertreter in Deutschland:
DIMAX International GmbH, Flinger Broich 203, 40235 Düsseldorf, Deutschland. Produziert in VRC.
support@dimaxgroup.com
www.konner-sohnen.com

European Union:

Manufactured under license and control of DIMAX International GmbH, Flinger Broich 203, 40235 Duesseldorf, Germany.

Importer and representative in Netherlands DIMAX International Poland Ltd, Południowa 8 st, 05-830 Stara Wieś, Poland. Assembled in PRC.
support@dimaxgroup.com
www.konner-sohnen.com

The United Kingdom:

Innovation Trade Ltd., 5th Floor,
167-169 Great Portland Street, London, W1W 5PF,
support@dimaxgroup.com
www.konner-sohnen.uk

France:

Fabriqu  sous licence et contr le de DIMAX International GmbH, Flinger Broich 203, 40235 D sseldorf, Allemagne.

Importateur et repr sentant en France et en Belgique DIMAX International Poland Ltd, Południowa 8 st, 05-830 Stara Wieś, Pologne. Assembl  en RPC.
support@dimaxgroup.com
www.konner-sohnen.fr

Esp  a:

Fabricado bajo licencia y control de DIMAX International GmbH, Flinger Broich 203, 40235 D sseldorf, Alemania.

Importador y representante en Espa  a de DIMAX International Poland Ltd, Południowa 8 st, 05-830 Stara Wieś, Polonia.
Ensamblado en la Rep blica Popular China.
support@dimaxgroup.com
www.konner-sohnen.es

Polska:

Wyprodukowano na licencji i pod kontrol  DIMAX International GmbH, Flinger Broich 203, 40235 Duesseldorf, Niemcy.

Importer i przedstawiciel w Polsce:
DIMAX International Poland Sp.z o. o. ul. Południowa 8, 05-830 Stara Wieś, Polska. Zmontowany w CRL.
support@dimaxgroup.com
www.konner-sohnen.pl

  kr  ina:

Виготовлено за л ценз єю та п д контролем DIMAX International GmbH, Flinger Broich 203, 40235 Д юссельдорф, Н меччина.

Імпортер та представник в   країні:
ТОВ "ТЕХНО ТРЕЙД КС" вул. Електротехнічна 47, 02225, м. Київ,   країна. Змонтовано в КНР

www.konner-sohnen.com.ua

